


Pumps and Irrigation Systems

Minimising the energy cost



Three Components

The irrigator – what is it designed to do?

The supply pipes



The pump and motor








How much water flow do you need?

Different irrigation methods require different pressure and flow combinations, travellers need pressure, laterals need higher flow at lower pressure

Minimise run-off water

The pump and pipe combination need to provide this end result with minimum energy loss.





Pipes and Water Flow

- Velocity
- Elbows
- Length
- Valves (part closed)

These four things determine the overall pressure and energy losses in the system



The Pump

Pumps are designed for specific pressure and flow combinations, move away from this and the efficiency will decline

Adding a stage to a turbine or axial pump will not increase the flow


					/ 🕊
CHANGE EFFIC.	NO. OF	NO. OF		PUMP MODEL 350FHM	CURVE NO.
AS FOLLOWS	POINTS	STAGES	Southern Cross	4405 B B M	E14131
LOWER	1	1 2		1485 R.P.M.	DATE
LOWER	0	3	EVERFLOW	BOWL DIA, 346 mm	May-2001
LOWER	Ť	Ť	VERTICAL TURBINE PUMPS	STANDARD CURVE ILLUSTRATES	
LOWER 2 PTS FOR PLAIN BOWL			TORDINE FUMPS	SINGLE STAGE PERFORMANCE ONLY	K 43
EFFICIENCIES SHOWN ARE PUMP EFICIENCIES - COLUMN & DRIVEHEAD LOSSES ARE NOT INCLUDED					
2510					
					NPSHR
22.5					5
A-1					(metres)
20					0
					∃ I
17.5 B					‡ I
					i I
15			60%		∃
"			65%		‡ I
12.5			70%	+++++++++++++++++++++++++++++++++++++++	i I
- HH		``		78%	∃
TOTAL				78%	‡ I
10			7	8.5%	i I
HEAD				70%	∃
7.5				65%	‡ I
(metres)				60%	‡ I
5					∃
 					‡
2.5					30
					INPUT
0 H				++++++	20
					POWER
					10
					- I
					(kW)
0 25 50 75 100 125 150 175 200 225 250 275 300					
VOLUMETRIC FLOWRATE (litres/second)					



The Pump

Changing the irrigation configuration may shift the pump to a less efficient point on the curve

Varying the speed of the pump allows the pump to match the conditions





Your Pump


Measure your current system

Flow - Pressure - Power

Calculate total dynamic head - Equivalent Length Method

- Turbine meters are notoriously inaccurate.
- Magnetic flow meters are both accurate and reliable





The Motor

Rewound electric motors use more electricity than new motors

High efficiency motors (IE3 or IE4) use less electricity than standard (MEPS) motors (IE2)

Pre MEPS motors are less efficient

The smaller the motor, the bigger the difference on all counts



Diesel engines

Match the pump and right angle drive to optimise the engine speed

Size the engine so that it is at an efficient point in its load curve (don't oversize it)

Turbo diesels are more efficient and worth the extra cost



Operation and Maintenance

To get the best out of your pumping system requires attention to detail

Pay attention to changes in sound

Don't just replace the bearings

Wear ring replacement minimises recirculation within the pump

Check for impeller wear



Case Study - Effect of main size


System to be expanded from 1 to 2 irrigators with lengthened 4" pipe, replacement pump.

With 4" main:


21.5 l/s, 59m head


With 6" main:

24.5 l/s 53m head



Case Study - Effect of main size





Case Study - Effect of main size

With the correct main size:

- 4% increase in power draw
- 14% increase in flow
- 9% reduction in energy cost per litre of water applied.

Questions?



